

## PUZZLE BREAK

DIP SW 1

SETTING	POSITION	1	2	3	4	5	6	7	8
DEMO	*SOUND OFF	OFF							
SOUND	SOUND ON	ON							
COIN/PLAY	*1COIN 1CREDIT		OFF	OFF	OFF				
	1COIN 2CREDIT		ON	OFF	OFF				
	2COIN 3CREDIT		OFF	ON	OFF				
	1COIN 3CREDIT		ON	ON	OFF				
	2COIN 1CREDIT		OFF	OFF	ON				
	3COIN 1CREDIT		ON	OFF	ON				
	4COIN 1CREDIT		OFF	ON	ON				
	5COIN 1CREDIT		ON	ON	ON				
GAME DIFFICULTY	*LEVEL 4					OFF	OFF	OFF	
	LEVEL 5					ON	OFF	OFF	
	LEVEL 6					OFF	ON	OFF	
	LEVEL 7					ON	ON	OFF	
	LEVEL 8					OFF	OFF	ON	
	LEVEL 1					ON	OFF	ON	
	LEVEL 2					OFF	ON	ON	
	LEVEL 3					ON	ON	ON	
TEST MODE	*GAME MODE TEST MODE								OFF ON